VISAR SOFTWARE USER MANUAL

www.visar-shop.com/

THANK YOU

Thank you for choosing YNK Software. This manual will guide you through all aspects of the software, from understanding the interface to mastering the advanced features that make YNK a powerful tool in your shop.

HOW TO USE THIS MANUAL

THIS MANUAL IS DIVIDED INTO 2 MAIN SECTIONS

INTERFACE OVERVIEW

This section will help you get familiar with VISAR's layout, tabs, and basic navigation. It's perfect for beginners looking to quickly understand how to move around the software

DATA CENTER

In the Data Center, users can select from a comprehensive range of data types for various applications. Some of the primary categories include:

Exterior of Car
Patterns and designs for vehicle body wraps and customizations.

Car Interior
Data for interior upholstery, detailing, and trim customization.

Window Film
Templates for automotive window tinting and protective films.

Motorcycles
Specialized data for motorcycle body wraps and customizations.

Mobile Electronic Equipment
Data for engraving and precise fine-tuning for mobile devices and electronic accessories.

Pattern Logo Engraving
Pre-loaded patterns for logo and artistic engraving projects.

Sunroof Ice Armor
Custom designs for sunroof protection and ice armor prevent

Car Partial Protection Kit
Data for applying protective film to specific parts of a vehicle, such as the hood or bumper.

In addition to these categories, the software supports a variety of other data types, offering flexibility to meet a wide range of cutting, engraving, and protective needs across industries.

SAVED VERSIONS

In the Saved Versions section, users can manage their custom data sets. This functionality allows users to:

Share
Easily share saved data versions with others, facilitating collaboration and data exchange.

Delete
Remove any saved data versions that are no longer needed.

Save
Securely store their customized or modified data for future use.

This feature provides users with full control over their data, ensuring flexibility and accuracy in managing their projects.

CROP RECORDS

The Crop Records section allows users to view a detailed history of all cutting operations performed. Key features include:

RECORD TRACKING
Access a complete log of previous cuts, including dates, settings, and data used.

REUSE
Easily retrieve and reuse past cutting records for repeated tasks, ensuring consistency and saving time.

This functionality ensures accurate project management by enabling users to reference and replicate previous cutting jobs with precision.

PERSONAL INFORMATION

In the Personal Information section, users can manage and review their account details, including:

ACCOUNT INFORMATION
View personal account details such as username and profile settings.

SUBSCRIPTION STATUS
Check the package details and any restrictions, including the maximum cutting area allowed under the current plan.

CHANGE PASSWORD
Easily update account security by changing your password.

This section provides users with full transparency and control over their account and subscription settings.

FEATURE GUIDE

Here, you'll learn about the key features of VISAR, including advanced tools like Super Nesting, editing functions, data management, and more. Each feature is explained with step-by-step instructions to help you maximize accuracy and get the most out of the software

PROJECTION
Projects the original data onto the canvas, allowing users to visually compare it with the edited version for accurate adjustments.

EXPAND
Automatically extends the edges of selected shapes with a single click, making it easy to increase the size or create borders.

INSET EXPANSION
Manually control the expansion or reduction of selected shapes. Use the mouse for adjustments and right-click to confirm the operation.

MOVE POINT
Data consists of individual points that can be selected and moved. Hold down the Shift key to select multiple points at once, then use the mouse or arrow keys to reposition them. Additionally, straight lines between points can be converted into curves by dragging with the mouse.

PEN
Draw rich straight lines and curves by clicking or clicking and dragging with the mouse, providing precision in creating and editing paths.

CROPPING
Modify shapes by directly cutting through node points. Hold Shift to select multiple nodes for cropping. Ideal for quickly refining shapes and creating custom designs.

DEL NODE
Remove unnecessary nodes from a shape. After deletion, the remaining nodes are automatically connected to a straight line, simplifying the shape while maintaining structure.

ADD NODE
Insert additional nodes into a shape, allowing for more detailed and refined edits.

CUTTING
Divides the cutting process. Users can preview the cut check cutting data (e.g., surface area and in-square meters), and select the cutting machine. It's recommended to set segments to at 300mm interval for minimize material waste.

BOTTOM
Sets the starting point for machine begin cutting from the bottom-left corner. this function ensures consistency and accuracy, properly aligned the machine before starting the job. To avoid errors caused by exceeding your machine's cutting width, it is recommended to use the Bottom alignment function before starting the cutting process. This helps minimize the risk of misalignment and ensures an accurate cut.

REFRESH
Reverts the canvas to its original state, after importing files or using the Super Nesting function, this ensures compatibility between various designs and the software.

SUPER NESTING
A unique and core feature of YNK software, designed to optimize material usage. For each vehicle, this feature will find the most efficient way to arrange the selected patterns on a layout width of 1470mm, and the longer you allow the nesting process to run, the better the results.

FILL COMMENT
Applies color fill to the data, making it easier to identify small or hard-to-distinguish elements and their actual placement on the vehicle, facilitating a smoother installation process.

DEL FEATURE
Allows users to delete unwanted elements from a design, such as radar holes or fuel tank covers. Select the unwanted data, with the left mouse button, then right click to confirm deletion.

COPY
Duplicates any of the design to copy using the left mouse button. Data can be pasted across decent designs, and you can use the Keyboard shortcut (Ctrl+C) for quicker operations.

COMBINE
Merge multiple designs together, enabling you to handle composite shapes or various material cuts.

DELETE
Removes selected elements from the design. This can also be done using the Delete key on your keyboard.

UNGROUP
Separates grouped elements so that individual parts can be edited or deleted independently.

MIRROR
Creates a mirrored version of the selected data. Click to select the mirror axis, drag the mouse, and right-click to confirm the mirrored copy.

SPLIT
Separates a split origin with the left mouse button, drag the mouse to create a new segment, and confirm the split by clicking again. This creates two separate elements.

UNDO
Reverses the last action, allowing you to backtrack to a previous state.

UNION
Combines the two or more designs into a single element.

REDO
Reverses a undo to the last undone action, exclusively reversing an undo.

ORIENTATION
Rotates the movement of tools like fan and blades to 0- straight lines or 45- diagonal angles for precise alignment.

MEASURE
Allows multiple measurements from one point to another using the left mouse button. Right-click to complete the first measurement or cancel it.

RECTANGLE
Enables users to draw rectangles by dragging the left mouse button, with a right-click confirming the shape.

CANCEL MEASURE
Cancels the ongoing measurement process.

CIRCLE
Allows users to draw circles by dragging the left mouse button, with a right-click to end the drawing.

SCALE
Resizes a selected shape to the desired dimensions, such as transforming a rectangle into a standard square.

IMAGE
Imports images into the design.

TEXT
Allows users to add text directly onto the canvas.

CANVAS
Sets the canvas size. The default canvas mimics standard PPF dimensions, set at 1470mm by 150,000mm.

3D IMAGING SYSTEM
Generates realistic engineering-generated images from our system, allowing for accurate 3D modeling.

IMPORT FILE
The Import feature allows users to import their own DXF format files directly into VISAR's software for full cutting and editing functionality. After importing, the data can be further refined via the Edit step to ensure optimal results. This feature provides flexibility for custom designs and ensures a smooth operation and integration with other tools and features within the software.

SHARE
The Share feature allows users to receive and access special data provided by VISAR's customer support team. By entering a unique share code, users can unlock hidden data or access custom data sets tailored specifically for their needs.

SAVED
The Saved feature empowers users to store their work directly in the Saved Versions module within the software. This ensures easy access and retrieval for future use and also provides the option to share the saved data with other users, facilitating collaboration and workflow scaling.

CHECK OUT THE SOFTWARE VIDEO TUTORIALS ON THE VISAR YOUTUBE CHANNEL

CLICK HERE